

 Safety Precautions:

- ### Product Specification:

Oil consumption means: the device in the maximum setting, the test oil is Shangri-La, the test oil consistency is 9.5MPA.S, the room temperature is 30 °C, the air humidity is 45%. Above is for reference.

-
- A diagram of a vertical cylindrical container. It has a lid with a textured top and a small handle on the side. A hand is shown pointing at the side of the cylinder. A double-headed arrow at the bottom indicates the diameter of the cylinder.

- 4.Remove bottle by rotating counter-clockwise, and fill in fragrance oil. then tighten it by clockwise rotation, put atomizing head back to machine, it locks up automatically.

Figure 1




Figure 3

Figure 2

The diagram illustrates the 'Setting' screen for the BLUETOOTH device, showing the process of modifying work mode settings.

Top Section (Main Settings):

- Name:** YGZK-XXJ-V3TJ-61F01F04 > (Name modification)
- Note:** Edit Note > (Remark modification)
- Fan switch:** Fan High > (Fan switch)
- Reset PWD:** (Modify Password)
- Work mode:**
 - Time: 00:00 - 23:59
 - Work: 60s Pause: 60s
 - Week: Mon, Tue, Wed, Thu, Fri, Sat, Sun

Bottom Section (Setting 1 - Detailed Work Mode Settings):

- Cancel** **Setting 1** **Confirm**
- Week:** Mon, Tue, Wed, Thu, Fri, Sat, Sun (Select the week to open)
- Period Time:**
 - Start: 00 : 00
 - End: 22 : 58
- Frequency:**
 - Work: 24s
 - Pause: 60s

Annotations:

- Up and down sliding adjustment:** Indicated for the Period Time and Frequency settings.
- Select the week to open:** Indicated for the Week selection.
- Working switch:** Indicated for the Work mode toggle.
- Add working mode:** Indicated for the '+' button.
- Delete work mode:** Indicated for the 'X' button.
- Click the work mode area to edit work mode:** Indicated for the Work mode section.

Device Fault	Solution
Device not work	A. Check if use wrong power supply; B. Check if the power is on; C. Check the setting of device work time.
No atomization	A. Check if the pump work normal, if the nozzle blocked; B. Check if the fog outlet seal ring broken or fall off; C. Check if the oil pipe blocked or fall off.
Weak atomization	A. Check if the seal ring of fog outlet pipe damage; B. Check if the nozzle blocked; C. Check if the connection of atomizer and nozzle loose.
Oil leak	A. Check if the atomizer broken; B. Check if the gasket broken and need change; C. Check if the connection of oil bottle and atomizer close tight
Abnormal noise	A. Pump loose,fix the pump; B. Pump broken,change new pump; C. Check if the fan fixed well.

Power Supply



Key



User Manual

The warranty period of the equipment is 1 year from the date of sale. Easily damaged accessories such as housing, wire and outer pipe are not covered by the warranty, and man-made damage and accident damage are not covered by the warranty. If the warranty period is exceeded, we will charge maintenance fees.

[illegible]



APP使用说明书:

1. 扫描封面的二维码或在应用商店搜索“香氛管家”app 下载并安装;
2. 打开香氛管家智能 APP 首页界面, 点击【蓝牙模式】(如图 1 所示);
3. 点击搜索出来的设备, 弹出密码输入对话框, 输入初始密码 9999, 进入工作设置(如图 2 所示)。



图1




图2

如忘记密码，快速按三次电源键（红蓝交替闪烁时）恢复初始密码（如图 3 所示）。

请使用产品前，仔细阅读本使用说明书并妥善保管

 安全注意事项:


1. 请勿使用过载电源；插座，以及破损的电源线和插头，如有使用可能会危及您的安全，并可能引起火灾，如有这种情况出现，请及时向销售或者售后部门反馈，并要求更换；
2. 请不要尝试打开产品的内部，以免损坏产品，产品使用如发生异常，请仔细阅读产品使用说明书，是否按照正常程序操作或者咨询销售和售后；
3. 设备在工作的时候，请勿拆卸设备，或者大力摇晃设备，这样会导致设备工作异常；
4. 请勿将产品或者电源适配器放置在水中或者淋水，勿使用淋水的电源适配器；
5. 在产品已经装有液体（精油）的情况下，请勿将产品倒置，倾斜或者旋转，以免液体溢出损坏产品；
6. 当碰到自然天气打雷的时候，不要操作设备或者触摸电源线，以免发生触电危险。

产品参数:


型 号	A300	A1000	A3000	A5000
精油容量	200mL	800mL	800mL	800mL
覆盖范围	500m²	1500m²	2000m²	3000m²
功 率	8W	13W	12W	13W
油 耗	2.5g±0.2g	5g±0.5g	6g±0.6g	8g±0.8g
机器尺寸	长: 160mm 宽: 86mm 高: 205mm	长: 200mm 宽: 140mm 高: 285mm	长: 250mm 宽: 140mm 高: 285mm	长: 170mm 宽: 140mm 高: 285mm
净 重	1.55kg	3.0kg	4.0kg	5.0kg
电 源	DC12V0.5A	DC12V1A	DC12V1A	AC100-240V
工作噪音	40dB	35dB	35dB	35dB
安装方式	摆放	摆放	摆放	摆放

油耗是设备最大档位，使用精油为测试用油（香格里拉），测试环境为：
精油粘稠度为 9.5MPA.S；室内温度为 30℃，空气湿度为 45% 仅供参考。

安装说明:



- A. 长按5秒关机
- B. 长按1秒开机
- C. 快速按3次恢复初始密码



1. 连接电源线;
2. 用磁感钥匙放在机器的解锁区域, 然后向上取出雾化头;
3. 按照箭头指引方向拔出雾化头;
4. 逆时针旋转取出精油瓶, 往精油瓶添加液体, 顺时针扭紧, 装入设备。

设备维护:

六个月维护一次，或者需要更换新的香味，以及发现香味越来越淡的时候

1. 打开设备下壳，取出使用完的精油瓶；
2. 每次更换精油都需要清洗精油过滤；
3. 将适量的酒精倒入精油瓶，清洗干净；
4. 检查雾化芯喷口是否干净，如果有发黑、积粉，可用牙签或纸巾清除。

故障排除:

问题故障	解决方案
设备不工作	A. 检查是否用错电源； B. 检查电源是否通电； C. 检查机器是否在“不工作期间”。
没有雾化	A. 检查气泵是否工作；雾化芯是否堵塞； B. 检查出气管密封圈是否破损或脱落； C. 吸油管是否堵住或脱落。
雾化小	A. 检查出气管密封圈是否破损； B. 检查雾化喷头是否堵住； C. 检查雾化芯与雾化头配合是否松动。
漏油	A. 雾化头是否破损； B. 垫片是否损坏需要更换； C. 精油瓶与雾化头是否拧紧。
异常噪音	A. 气泵松动，重新固定好气泵； B. 气泵损坏，更换新的气泵； C. 检查风扇是否固定好。

包装配件:



电源



钥匙



说明书

售后服务:

设备至卖出日起，一年内保修，但不保修外壳，电线及外置的喉管等易损件，人为或者意外造成的损坏亦不在保修范围内，超出免费保修期实行有偿维修。

保修卡:

[illegible]