


B5000 User Manual



Please read the user manual carefully before using the product and keep it in a safe place.

Safety Precautions :

1:Do not use overloaded power supplies, sockets, and damaged power cords and plugs. If used, it may endanger your safety and may cause fire. If this happens, please promptly report to the sales or after-sales department and request replacement.

2:Please do not open the inside of the device to avoid the device damage. If the device works in error, please read the user manual carefully, follow the normal procedure or consult sales and after-sales.

3:When the device is working, do not disassemble the device or shake the device vigorously, to avoid the device to work abnormally.

4:Do not put the device or power adapter in water or watering, do not use a watering power adapter.

5:When the device is already filled with liquid (essential oil), do not invert, tilt or rotate the device to device liquid spillage and damage the device.

6:When encountering natural weather thunder, do not operate the device or touch the power cord to avoid the risk of electric shock.

Product Instruction:

B5000 has independent intellectual property rights of a particle screening structure and double essential oil anti-oxidation, it can keep the scent in the best condition from the beginning to the end, the particles will not attach on the surface of object, the scent will keep strong for a long time. B5000 adopts double air supply system, can be controlled independently, with two atomization systems for space diffusion, widely used in central air conditioning system (HVAC), its features are: fast scent diffusion speed, large scent diffusion area, high class of intelligence control.




B5000 uses professional diaphragm pump which can work 10000 hours, it works stable and has a long using lifespan. The device adopts microcomputer intelligent control, with five events. Each event can independently set the time and oil concentration. Two 1000ml essential oil containers can work for a long time.

Product Specification:


Model No	B5000	Machine Size	285*260*322mm
Oil Capacity	1000ML*2	N.W	7.5kg
Coverage Area	10000m³	Voltage	DC12,V2A
Power	20W	Noise	40db
Oil Consumption	5.5g±0.5g	Install Method	HVAC

Oil consumption means: the device in the maximum setting, the test oil is Shangri-La, the test oil consistency is 9.5MPa.S, the room temperature is 30 °C, the air humidity is 45%. Above is for reference.


Install Instruction:




1:Place the atomizer hanging plate on the screw which is in the side of main body, connect the power supply, turn on the power switch, the power light bright and the device goes into standby.



2:Remove the oil bottle, turn the atomizer counterclockwise to take off it from the bottle, put liquid into the bottle, tighten the atomizer on the bottle clockwise and put it on the hanging plate.




3: Connect the corresponding pipe to the corresponding atomizer, two atomizer can be switched at will.



4: Connect the fog guiding pipe, set the working time, the signal light bright means it works, if only need one group work, turn on the switch of this group, and turn off the switch of the other group.

Settings:



1: Power On

Connect power supply, press switch A or B, the signal light bright and the corresponding screen lights up automatically, means the device is turned on and can work normal, the screen shows the factory setting of the time, date and the working mode, the two air supply system can work simultaneously.

2:Setting Local Time

Press SET for 5 seconds to activate the time setting interface; press ▲▼ to set the hour, press SET to confirm and start minute setting, press ▲▼ to set minutes, press SET to confirm and start the week setting, press ▲▼ to select the work day, press SET to confirm and the time setting is end. The system automatically saves the settings.

3:Working Time Setting, Atomizing Gear Setting

First time press MODE to enter the working start time setting, press SET to activate the hour setting, press  to set hour, press SET to confirm and start minute setting, press  to set minute, press SET to confirm and star week day setting, press  to select the day of week, press  to cancel the day of week, press SET to confirm and the working start time setting is finished.

Second time press MODE to enter the working end time setting, press SET to activate the hour setting, press▲▼to set hour, press SET to confirm and start minute setting, press▲▼to set minute, press SET to confirm and the working end time setting is finished.

Third time press MODE to enter the scent work setting, press   to set the scent work time; the scent work time is from 5-300 seconds, from 5-100seconds press  the interval is 5 seconds, from 100-300seconds press  the interval is 10 seconds, then scent concentration setting is finished.

Fourth time press MODE to enter scent pause time setting; scent pause time is 5-300 seconds, press   to set the pause time, 10-100s interval is 5 seconds, 100-300s interval is 10 seconds, then the work pause time setting is finished. The work pause time setting of the other 4 events, repeat above setting is ok.

Note: Each event can control 24 hours only, if out of range, will switch to last event automatically, if necessary, can setting by 2 events. System time is 00:00-23:59, for example, work start in 22:00, end in 2:00, should set by 2 events, the setting method is 1st event 22:00-23:59, 2nd event 00:00-2:00, the work time among each events could not repeat, otherwise the system could not recognize.

5:Scent Work Time Quick Setting

At current work event, press ▲ can set the scent work time, press ▲ increase the scent work time, press ▼ reduce the scent work time. The scent pause time can set in this ways as well, after setting the scent work time, press MODE to enter scent pause setting, then the device save the setting automatically. (This function use for current work event only, other events which not in the work time, should enter into the work event to setting the scent work time.)

6:Restore Factory Setting

Long press MODE for 10 seconds, the device is restored to factory setting, the first work event of factory setting is 8:00-22:00, scent concentration is 60:60, the work time of other 4 events are all 00:00-00:00.

Device Maintains:

Maintain the device every 6 months, or replace the essential oil if the scent weaker

1. Open the device cover, take off the oil bottle.
2. Each time replace the essential oil, should clean the oil pipe filter.
3. Put some alcohol into the oil bottle and use the alcohol clean the oil bottle.
4. Put few alcohol into the oil bottle, install the bottle to the device, power on the device and work 5 minutes.
5. Replace the PE gasket.

Fault Resolution:

Device Fault	Solution
Device not work	-Check if use wrong power supply. -Check if the power is on. -Check the setting of device work time.
No atomization	-Check if the pump work normal, if the nuzzle blocked. -Check if the fog outlet seal ring broken or fall off. -Check if the oil pipe blocked or fall off.
Weak atomization	-Check if the seal ring of fog outlet pipe damage. -Check if the nozzle blocked. -Check if the connection of atomizer and nuzzle loose.
Oil leak	- Check if the atomizer broken. - Check if the gasket broken and need change. - Check if the connection of oil bottle and atomizer close tighten.
Abnormal noise	-Pump loose, fix the pump. -Pump broken, change new pump. -Check if the fan fixed well.

Packing Accessories:

				
Power Supply	Air Pipe	User Manual	Screw	Fast Connector

After Sale Service:

The warranty time of the device is 1 year from the date of sale, the cover, electric wires, external tube and other easy damage accessories not in the warranty range, man-made damage and accident damage not in the warranty range as well. We will charge for the maintain if out of the warranty time.

Warranty Card:

Maintain Date	Maintain Item	Maintain Company	Maintain Staff