


### 产品说明书




**产品：A603**

|              |                |                   |
|--------------|----------------|-------------------|
| 功率：3W        | 输入电压：5V≐0.6A   | 净重：320g           |
| 材料：ABS+PP    | 覆盖范围：10-30 m³  | 内置电池：2000mAh      |
| 尺寸：φ76*124mm | 瓶子容量：5/10/15ml | 精油粘度：10-46.5mpa.s |

### 产品介绍



### 操作流程



### 产品介绍

**充电模式**  
充电时，指示灯红灯常亮，充满电后，绿灯常亮  
(注：是指按钮处灯光)  
充电时间：约4小时充满（注：机器电量耗尽时需至少充电5分钟后才能再次工作）

**智能关机**  
在没有操作的状态下，3小时后自动关机。

**颜色氛围灯**  
一共设置了9种灯光颜色，分别红色,橙色,黄色,绿色,蓝色,靛色,紫色,粉色，白色；还有一个档位是关灯键，可以让你有更多选择。

**雾化头**  
在大多数情况下可以适用市场上5/10/15ml三种规格的精油瓶，雾化头瓶口设置通用。

**按键**  
开/关键：长按，开关机，短按切换档位。  
氛围灯控制键：短按切换颜色灯光。

**低电量提醒**  
当机器处于较低电量时，机器氛围灯会变成红色且不断闪烁。

| 档位 | 工作时间(s) | 停止时间(s) | 雾化量(g/h) |
|----|---------|---------|----------|
| G3 | 10      | 60      | 0.13     |
| G2 | 10      | 120     | 0.07     |
| G1 | 5       | 150     | 0.03     |

### 注意事项


⚠ 1.安装后请将机器保持垂直。倾斜或平躺可能导致溢油。  
如果电路板受到污染,机器效率可能会受到影响。

2.不得随意改装、拆卸或修理机器。任何故障发生,请及时与相关技术人员联系。


3.不得把机器放到高温，潮湿的地方，以免损坏机器。

4.产品不建议在环境温度60度以上使用。

注意：雾化头不是盖子，在工作时，机器要保持直立，以免漏水和损坏使用机器盖的密封匹配。




### 产品说明书



**A603 家用**


# Product Manual



**Model: A603**


|                      |                             |                             |
|----------------------|-----------------------------|-----------------------------|
| Power: 3W            | Input Voltage: 5V±0.6A      | N.W: 320g                   |
| Materials: ABS+PP    | Coverage: 15m³/45m³/1600ft³ | Bottle: 5/10/15ml           |
| Dimension: φ76*124mm | Li-battery: 2000mAh         | Essential oil: 10-46.5mpa.s |

## Product Description:



Machine, USB cable, Manual

## User Guide:



- 1.Take out the diffuser head
- 2.Turn the bottle counterclockwise
- 3.Press down the diffuser head
- 4.Long press to switch the machine
- 5.Click to change the grades
- 6.Click to switch the light color

## Function Description:

**Charging mode**  
When charging, the indicator light is always red, and when fully charged, the green light is always on.  
(Note: it refers to the charging indicator on the back)  
charge time: about 4h(When the battery is exhausted, it needs to be charged for at least 5 minutes before it can work again.)  
Battery duration: about 24h(working at G1)

**Auto power off**  
When there is no operation, the device will automatically power off after 3 hours.

**Ambient light**  
Total 9 light colors, they are red, orange, yellow, green, cyan, blue, purple, pink, white.

**Diffuser head**  
Applied to most 5/10/15ml bottles in the market.

**The Buttons**  
On/Off button: long press to switch the machine, short press to change grades.  
Ambient light button: Press to change the light color or turn off the light.

| Grade | Working time(s) | Stop time(s) | Consumption (g/h) |
|-------|-----------------|--------------|-------------------|
| G3    | 10              | 60           | 0.17              |
| G2    | 10              | 120          | 0.07              |
| G1    | 5               | 150          | 0.03              |


## Cautions:

- 1. Please keep the machine vertical after installation. Tilting or lying flatly may cause oil overflow. The machine efficiency may be affected if the circuit board is contaminated.
- 2. Should not modify, dismantle or repair the machine arbitrarily. Any malfunction occurs, please contact with relevant technician in time.
- 3. Do not put the machine in a hot or humid place to avoid damage to the machine.

Do NOT use quick charger for device.

Do NOT use or store the device above 60°C.

Note: The machine should be kept vertically to avoid leakage and damage when working.



## Trouble shooting:

Before asking to have the machine repaired, please try to diagnose the problem first following to below instructions.

| Breakdown      | Solution                                                                                                                                                                                                                                          |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Do not diffuse | -The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.<br>- Air pump may be damaged, please replace a new one.<br>-The tube may be loose, please check and tighten it.                         |
| Weak diffuse   | -The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.<br>-The gasket may be damaged or loose, please tighten it or replace a new one.<br>-The tube may be loose, please check and tighten it. |
| Oil leakage    | -The bottle may be loose, please check and tighten it.<br>-The gasket in the atomized head is damaged or loose, please tighten it or replace a new one.                                                                                           |
| Oil spill      | -The atomized head may be damaged, please replace a new one.<br>-The machine is tilted or lie flat, please keep it upright.                                                                                                                       |
| Abnormal noise | -The air pump may be loose, please check and tighten it.<br>-The air pump may be damaged, please replace a new one.                                                                                                                               |